


CartStopCG

Slimline Guard and Shock Absorbing Flange Anchor


Installation Instructions




CartStopCG

Slimline Gard and Shock Absorbing Flange Anchor


Components



18" and 12" Slimline Guard
18" Pt No: Guard-18-LP-Colour Code
12" Pt No: Guard-12-LP-Colour Code



Stainless Steel Flange Socket
Pt No: CSF-10




Shock Absorbing Flange Anchor
Pt No: CSF-RFA


CartStopCG

Slimline Gard and Shock Absorbing Flange Anchor


Tools




**Pencil/Marker &
Chalk Line**




Tape Measure



Hammer Drill



**30mm SDS Drill Bit
(Hammer drill bit)**



Rubber Mallet


CartStopCG

Slimline Gard and Shock Absorbing Flange Anchor

Installation Details



General Layout




CartStopKK

Slimline Gard and Shock Absorbing Flange Anchor

Installation Details




1.1.




Measure and mark out offset from fixture
The offset should be 50mm from the edge of the fixture
(Ref: 'General layout')

1.2.




Position the gard on top of the marked out line and draw around the legs in position.

1.3.




Ensure that the leg centre markings are equally spaced

1.4.



Using an SDS hammer drill and a 30mm SDS drill bit drill the 2 holes for the flanges
(Ensure the holes are drilled straight and perpendicular to each other)

1.5.



Ensure all holes are clear of any drilling debris and dust. Align the shock absorbing flange anchors with the holes and knock in using a rubber mallet


CartStopCG

Slimline Gard and Shock Absorbing Flange Anchor

Installation Details




1.7.




Align the stainless steel flanges with the shock absorbing flanges and knock into place with a rubber mallet where required lubricate the fitment with washing liquid

1.8.



Insert the Gard into the flanges and ensure that the guard sits straight

1.9.



**Clear away any dirt and debris
INSTALLATION COMPLETE**